ADDENDUM

USB Mode Digital Camera

Cat. No. 25-3009

The operation manual for the supplied PhotoBank Video Capture program is on the CD-ROM, but it is not automatically copied to your computer when you install the software. We recommend that you copy *VideoCap Manual.pdf* from the *PBank* folder to the same folder in which you installed PhotoBank Video Capture.

When saving a captured image, Video Capture lets you choose between BMP or JPG format. If you select JPG, be sure to add the .jpg extension when you enter the file name; otherwise, the program automatically adds the .bmp extension.

© 2001 RadioShack Corporation. All Rights Reserved. RadioShack and RadioShack.com are trademarks used by RadioShack Corporation.

RadioShack Corporation
Fort Worth, Texas 76102

25-3009
09A01
Printed in Korea